Level Line

[This line should measure 4 inches.]

WALL MOUNTING INSTRUCTIONS

Before you begin: Add your photo to the frame first. You'll need a Phillips screwdriver, a level, a pencil, and painter's tape. The included anchors are for drywall.

1. Position the template. Tape it lightly to the wall where you want the frame. Set a level on the printed level line, adjust until it's straight, then press the tape down firmly.

2. Mark the holes. Press a pencil tip through the center of each X. Remove the template.

3. Install the anchors. Press the point of an anchor into each mark and turn it clockwise with a screwdriver until it sits flush with the wall. Stop once it's flush, because turning further can strip the drywall.

4. Attach the bases. Hold a standoff base over each anchor and drive the screw through it into the anchor until snug.

5. Hang the frame. Set the frame over the bases and screw on the caps. Tighten by hand only, since overtightening can crack the acrylic.